



J4125 (RTL8125b 2.5Gb) ()

USB*2 + USB1

() ISO

()

<https://github.com/dgparker/RTL8125-proxmox-ve-install-script>

()+USB*2+USB() J4125 ()

() USB ()

() Install Proxmox VE (Debug Mode)

() Ctrl + D ()

#1. ()

mkdir /mnt/usb

#2. ()

mount /dev/sdc2 /mnt/usb

#3. ()

cd /mnt/usb

#4. () deb . sh() /tmp

/cp () /tmp

#5. () /tmp ()

cd /tmp

```
#6. 設定 setup.sh の実行権限
```

```
chmod +x setup.sh
```

```
#7. 実行
```

```
./setup.sh
```

```
#8. 確認
```

```
#9. 確認 USB ケーブルが接続されているか
```

```
#lsusbコマンドで確認
```

確認完了後 Ctrl + D を入力して終了

確認完了後 USB ケーブルを接続

確認完了後 10分程度待機

確認完了後 10分程度待機

確認完了 root ユーザーで実行

確認完了 1~7 の手順を確認

```
nano /etc/network/interfaces
```

確認完了 bridge-ports の設定を確認 enp1s0

```
auto lo
```

```
iface lo inet loopback
```

```
#USB
```

```
iface enxd03745ecf4bf inet manual
```

```
#
```

```
iface enp1s0 inet manual
```

```
#
```

```
iface enp2s0 inet manual
```

```
#
```

```
iface enp3s0 inet manual
#
iface enp4s0 inet manual

auto vmbr0
iface vmbr0 inet static
    address 10.10.2.254/24 #IP
    gateway 10.10.2.1
    bridge-ports enp1s0 #
    bridge-stp off
    bridge-fd 0
```

Ctrl + O Ctrl + X

```
systemctl restart networking.service
```

PVE IP

Revision #5

Created 29 December 2022 15:28:39 by

Updated 29 December 2022 15:45:15 by